


# Whirlpool WGD5550XW0 01 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool WGD5550XW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096984		Not Available	INSTALLATION (INSTRUCTIONS)
"	W10097012		Not Available	GUIDE, USE & CARE
"	W10096965		Not Available	TECH SHEET
2	<a href="#">W10269609</a>			Console Assembly
3	<a href="#">W10251392</a>			Knob Assembly
4	<a href="#">W10269624</a>			User Interface Assembly
5	<a href="#">3394427</a>			Clip-Harness
6	<a href="#">W10274524</a>			Tensioner, Facia
7	<a href="#">94614</a>			Terminal
8	<a href="#">W10285495</a>			Cable, User Interface
9	<a href="#">W10096969</a>			Panel, Rear Console
10	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">3391018</a>			Tie Cable
12	<a href="#">W10260246</a>			Top
13	3390647	<a href="#">488729</a>		Screw

14	<a href="#">8312709</a>		Clip-Console
15	<a href="#">W10297565</a>		Cover, Terminal Block
16	<a href="#">W10279552</a>		Plug-Upper Rear Panel
17	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">8536939</a>		Clip, Knob
19	<a href="#">W10253982</a>		Harness, Wiring
20	337686	Not Available	SCREW, 8-18 X .500
21	<a href="#">W10219342</a>		Screw, Baffle Mounting
22	<a href="#">W10271580</a>		Bracket, Motor Control
23	W10331077	<a href="#">W10317636</a>	Control, Electronic

