


# Whirlpool WGD5700AC0 01 - TOP AND CONSOLE PARTS



5-12 Printed in U.S.A. (BMN) (psw)

1

Part No. W10503111 Rev. A

Whirlpool Residential Whirlpool WGD5700AC0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10115228		Not Available	INSTRUCTIONS, INSTALLATION
"	W10097053		Not Available	GUIDE, USE & CARE
"	W10417013		Not Available	TECH SHEET
2	<a href="#">W10458788</a>			Console Assembly
3	<a href="#">W10251394</a>			Assembly, Knob White And Silver Models
4	<a href="#">W10269626</a>			User Interface Assembly
5	<a href="#">W10323092</a>			Seal, User Interface
6	<a href="#">W10274524</a>			Tensioner, Facia
7	<a href="#">W10123956</a>			Dampening Panel
8	<a href="#">W10285494</a>			Cable, User Interface
9	<a href="#">W10096969</a>			Panel, Rear Console
10	<a href="#">693995</a>			Screw, Hex Head
11	<a href="#">W10325119</a>			Spacer, Knob
12	<a href="#">W10458665</a>			Top
13	3390647	<a href="#">488729</a>		Screw

14	<a href="#">8312709</a>		Clip-Console
15	<a href="#">W10338363</a>		Cover, Terminal Block
16	<a href="#">W10279552</a>		Plug-Upper Rear Panel
17	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">8536939</a>		Clip, Knob
19	<a href="#">W10287253</a>		Harness, Wiring
20	<a href="#">W10298336</a>		8-18 Nch, U-Type NUT
21	<a href="#">W10219342</a>		Screw, Baffle Mounting
22	<a href="#">W10271580</a>		Bracket, Motor Control
23	<a href="#">W10214008</a>		Control, Electronic
24	<a href="#">W10280079</a>		Seal, Console

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>