


Whirlpool WGD5700AC0 04 - W10293911 BURNER ASSEMBLY

W10293911 BURNER ASSEMBLY

For Model: WGD5700AC0
(Silver)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10503111

7

Whirlpool [Residential Whirlpool WGD5700AC0 Dryer Parts](#) Parts Diagram 04 - W10293911 BURNER ASSEMBLY
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|---------------|------------------------------------|
| 1 | W10293911 | W10310204 | | Burner-Gas |
| 2 | 688617 | 693140 | | Burner |
| 3 | 694298 | | | Bracket, Ignitor |
| 4 | 686590 | 279311 | | Ignitor |
| 5 | 3393909 | | | Screw, 8-32 X 7/8 |
| 6 | 343641 | 681414 | | Screw, 10AB X 1/2 |
| 7 | 3389871 | | Not Available | Base, Burner |
| 8 | 3387057 | | | Screw, 10-16 X 1/2 Orifice, Burner |
| 9 | 15418 | | | Orifice, Burner Type 1 |
| 10 | W10175144 | W10293912 | | Valve-Gas |
| 11 | W10295524 | W10328463 | | Coil, 60 Hz |
| 12 | 3389889 | | | Bracket, Support |
| 13 | W10273784 | W10328463 | | Coil, 60 Hz |
| 14 | 3978776 | | | Bracket, Gas Pipe Switch |
| 15 | 326049536 | | | Screw, Coil |
| 16 | 3390647 | 488729 | | Screw |

