


# Whirlpool WGD5700XL0 01 - TOP AND CONSOLE PARTS



9-10 Printed in U.S.A. (BT) (eeb)

1

Part No. W10330980 Rev. B

Whirlpool [Residential Whirlpool WGD5700XL0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096984		Not Available	INSTALLATION (INSTRUCTIONS)
"	W10096985		Not Available	GUIDE, USE & CARE
"	W10097034		Not Available	TECH SHEET
2	<a href="#">W10269611</a>			Console Assembly
"	<a href="#">W10293251</a>			Console Assembly
3	<a href="#">W10251394</a>			Assembly, Knob White And Silver Models
4	<a href="#">W10269626</a>			User Interface Assembly
5	<a href="#">3394427</a>			Clip-Harness
6	<a href="#">W10274524</a>			Tensioner, Facia
7	<a href="#">94614</a>			Terminal
8	<a href="#">W10285494</a>			Cable, User Interface
9	<a href="#">W10096969</a>			Panel, Rear Console
10	<a href="#">693995</a>			Screw, Hex Head
11	<a href="#">3391018</a>			Tie Cable
12	<a href="#">W10260246</a>			Top

"	<a href="#">W10268729</a>		Top
13	3390647	<a href="#">488729</a>	Screw
14	<a href="#">8312709</a>		Clip-Console
15	<a href="#">W10297565</a>		Cover, Terminal Block
16	<a href="#">W10279552</a>		Plug-Upper Rear Panel
17	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">8536939</a>		Clip, Knob
19	<a href="#">W10287253</a>		Harness, Wiring
20	<a href="#">W10298336</a>		8-18 Nch, U-Type NUt
21	<a href="#">W10219342</a>		Screw, Baffle Mounting
22	<a href="#">W10271580</a>		Bracket, Motor Control
23	W10253975	<a href="#">W10347319</a>	CCU-Control
24	<a href="#">W10280079</a>		Seal, Console
25	<a href="#">W10325119</a>		Spacer, Knob

