


Whirlpool WGD6200SW0 04 - 8557890 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED)

8557890 BURNER ASSEMBLY

For Model: WGD6200SW0
(White)

USE WITH TYPE 1 - NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



8181281

7

Whirlpool [Residential Whirlpool WGD6200SW0 Dryer Parts](#) Parts Diagram 04 - 8557890 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED).
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8557890			Burner, Assembly 60 Hz
2	688617	693140		Burner
3	694298			Bracket, Ignitor
4	686590	279311		Ignitor
5	3393909			Screw, 8-32 X 7/8
6	3390631			Screw, 10-16 X 3/8
7	8544751			Base, Burner
8	3387057			Screw, 10-16 X 1/2 Orifice, Burner
9	234826			Orifice, Burner Type 1
"	229742			Orifice, Burner
"	234868			Orifice, Burner
10	8281924	W10503171		Gas Valve Serv Assembly Loop
11	694421			Screw, Bracket Mounting

12	8182790		Bracket, Coil
13	694540		Coil, 60 Hz
14	694539		Coil, 60 Hz
15	694424		Leak, Limiter
16	694423		Screw, Regulator Adjustment
17	694422		Spring, Regulator
"	BLANK	Not Available	Following Parts Not Illustrated
"	49572	49572A	Conversion Kit To Type L.p.g.f
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	346764		Kit, Hold Down
"	W10071550	W10071550A	Dryer Rack
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

