


# Whirlpool WGD6200SW2 02 - CABINET PARTS



Whirlpool [Residential Whirlpool WGD6200SW2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8533974	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
2	<a href="#">3390631</a>			Screw, 10-16 X 3/8
3	<a href="#">693995</a>			Screw, Hex Head
4	<a href="#">3387374</a>			Spring, Idler
5	<a href="#">8558833</a>			Plate, Cover Terminal Block
6	<a href="#">8566208</a>			Assembly, Switch
7	8558830		Not Available	Panel, Rear
8	<a href="#">8568303</a>			Locator, Snap Down
9	8572983	<a href="#">W10295405</a>		Strike
10	3978977	<a href="#">W10201787</a>		Switch-Dor
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">W10050060</a>			Filler-Door
13	<a href="#">8578538</a>			Restrainer, Belt
14	<a href="#">8578560</a>			Hole, Plug
15	<a href="#">8565018</a>			Assembly, Hinge And Pin
16	3392100	<a href="#">49621</a>		Feet-Leveling

"	<a href="#">279810</a>		Foot-Optional
17	342055	<a href="#">488627</a>	Screw
18	W10183827	<a href="#">W10223154</a>	Cabinet
19	<a href="#">W10007520</a>		Clip, Ground
20	<a href="#">8576625</a>		Lock, Front Top
21	8565033	<a href="#">W10174287</a>	Panel
22	<a href="#">8564011</a>		Bracket-Switch
23	<a href="#">3404413</a>		Plug, Hinge Hole
24	8572982	<a href="#">W10111905</a>	Assembly, Door Catch
25	W10130493	<a href="#">W10239307</a>	Seal-Door
26	<a href="#">308499</a>		Nut-1/4 Hf Self-Thread
27	<a href="#">8539897</a>		Jumper,
28	<a href="#">W10100830</a>		Screw, 10-16 X 3/64
29	<a href="#">8539897</a>		Jumper,
30	<a href="#">8565020</a>		Door, Inner
31	<a href="#">W10116924</a>		Door Outer
32	W10111244	<a href="#">W10196276</a>	Handle
33	<a href="#">W10044490</a>		Seal, Front Panel
34	<a href="#">8564457</a>		Plug, Front Panel
35	344020	<a href="#">3401402</a>	Cord, Power
36	<a href="#">3394083</a>		Clip, Front Panel
37	238088	<a href="#">8066217</a>	Hinge, Top
38	<a href="#">8547174</a>		Idler And Pulley Assembly
39	<a href="#">8547168</a>		Belt, Drive
40	<a href="#">8547166</a>		Base, Motor
41	<a href="#">W10002600</a>		Screw, 6-20 X 1 1/4
42	<a href="#">8578565</a>		Pulley, 60 Hz
43	8566152	<a href="#">W10463866</a>	Motor-Drve
44	<a href="#">W10121316</a>		Plug, Multivent
45	<a href="#">W10183825</a>		Burner, Assembly 60 Hz
46	<a href="#">W10121334</a>		Washer, Thrust
47	<a href="#">8564010</a>		Assembly, Switch And Actuator

