


Whirlpool WGD6600WL0 01 - TOP AND CONSOLE PARTS



4-09 Litho in U.S.A. (LT)(bay)

1

Part No. W10268518 Rev. A

Whirlpool Residential Whirlpool WGD6600WL0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150650		Not Available	Guide, Quick Start
"	W10164752		Not Available	Guide, Quick Start
"	W10156038		Not Available	Wiring Diagram
"	W10166439		Not Available	Performance, Tip Sheet
"	W10139322		Not Available	TIP SHEET DRYER STEAM
2	W10051165			Assembly, User Interface
3	W10252836			Panel, Console
4	W10003770			Screw, 6-19 X 1/2
5	717252			Receptacle, Terminal
6	8564265			Cover, Rear- User Interface
7	W10212211		Not Available	Knob, Control (Aluminum)
8	337686		Not Available	SCREW, 8-18 X .500
9	94614			Terminal
10	8572270			Assembly, Lint Screen
11	W10249709			Cover, Lint Screen
12	W10044470			Hinge, RH

"	W10044480		Hinge, L.H.
13	3196537	3196557	Panel, Manifold
14	3936144		Do-It-Yourself Repair Manuals
15	3395683		Receptacle, Multi-Terminal
16	W10249705		Top
17	343641	681414	Screw, 10AB X 1/2
18	8558863		Bracket, Console
19	3394427		Clip-Harness
20	94613	596797	Terminal
21	8563853		Bracket, Machine Controller
22	W10111616		Control, Electronic
23	3347243		Block, Disconnect
24	353424		Plug, Terminal
25	3401144		Connector
26	3403499		Connector, 2-Position
27	3403498		Connector, 3-Position
28	W10141981		Harness, Wiring
29	W10112673		Screw, Grommet
30	237446	487596	Washer
31	W10183819		Seal-Foam Console
32	W10131402		Screw, 8-18 X 1.370

