



**NON – ILLUSTRATED  
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



[Whirlpool Residential Whirlpool WGD7300XW0 Dryer Parts](#) Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	<a href="#">8522199</a>			Accessory Parts
"	<a href="#">346764</a>			Kit, Hold Down
"	<a href="#">49611</a>			Kit, Side Venting
"	8544761	<a href="#">8544761A</a>		Exten-Exht
"	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )