


Whirlpool WGD7800XB0 02 - CABINET PARTS



Whirlpool Residential Whirlpool WGD7800XB0 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|--|
| 1 | W10007520 | | | Clip, Ground |
| 2 | 8544753 | | | Bracket, Burner |
| 3 | 3390631 | | | Screw, 10-16 X 3/8 |
| 4 | 8558833 | | | Plate, Cover Terminal Block |
| 5 | W10314253 | | | Switch, Assembly Broken Belt |
| 6 | 344020 | 3401402 | | Cord, Power |
| 7 | W10183827 | W10223154 | | Cabinet |
| " | W10183831 | | | Cabinet |
| " | W10183832 | W10223156 | | Cabinet |
| 8 | 3392100 | 49621 | | Feet-Leveling |
| NI | 279810 | | | Foot-Optional |
| 9 | 660658 | | | Clamp, Motor Mounting 343481 685441 |
| 10 | 3387374 | | | Spring, Idler |
| 11 | 3389420 | | | Retainer-Idler 1/4-20 X 1/16 |
| 12 | 8578931 | | | Window, Outer Door |
| 13 | 8547160 | | | Pulley Assembly |

| | | | |
|----|---------------------------|---------------------------|------------------------|
| 14 | W10201446 | | Bracket-Gas Pipe |
| 15 | 8578560 | | Hole, Plug |
| 16 | 8571357 | | Door, Inner |
| " | W10307042 | | Door, Inner |
| 17 | W10111888 | | Plug, Strike |
| 18 | 18849 | | Pad, Top Hinge |
| 19 | 3394083 | | Clip, Front Panel |
| 20 | 8533974 | 4331106 | Screw, No.10-32 X 7/16 |
| 21 | 8579717 | | Assembly, Hinge |
| " | W10111912 | | Assembly, Hinge |
| " | W10252472 | | Hinge Assembly |
| 22 | 3400805 | | Screw, 8-18 X 3/64 |
| 23 | 8571365 | | Door, Outer |
| " | W10307048 | | Door, Outer |
| " | W10307050 | | Door, Outer |
| 24 | W10111883 | W10312757 | Panel |
| " | W10194731 | W10223443 | Panel |
| " | W10252446 | W10283294 | Panel |
| 25 | 8558846 | | Glass, Inner Door |
| 26 | 3393657 | | Restrainer, Belt |
| 27 | 8547170 | W10448896 | Motordrve |
| 28 | 8558830 | Not Available | Panel, Rear |
| 29 | 8544743 | | Pulley, Blower |
| 30 | 8547157 | | Belt, Drive |
| 31 | W10076050 | | Seal, Window |
| 32 | 8547158 | | Bracket, Motor |
| 33 | W10111905 | | Assembly, Door Catch |
| 34 | W10002600 | | Screw, 6-20 X 1 1/4 |
| 35 | 8568303 | | Locator, Snap Down |
| 36 | W10157932 | | Seal, Foam Cabinet |
| 37 | W10111906 | W10295405 | Strike |
| 38 | W10144494 | | Plug-Hole |
| 39 | W10221653 | W10239307 | Seal-Door |
| 40 | 342055 | 488627 | Screw |
| 41 | W10201785 | | Door Switch Assembly |
| 42 | 8547171 | | Pulley, |
| 43 | 8576625 | | Lock, Front Top |
| 44 | W10044490 | | Seal, Front Panel |
| 45 | 8564457 | | Plug, Front Panel |
| " | 8573008 | | Plug, Front Panel |
| " | W10249704 | | Plug, Front Panel |
| 46 | 238088 | 8066217 | Hinge, Top |
| 47 | 308499 | | Nut-1/4 Hf Self-Thread |
| 48 | W10123956 | | Dampening Panel |