


Whirlpool WGD8200YW1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: WGD8200YW1
(White)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

12-11 (Printed in U.S.A. (BMN) (psw)

1

Part No. W10479132 Rev. A

[Whirlpool Residential Whirlpool WGD8200YW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10403269		Not Available	TECH SHEET
"	W10398830			Guide, Use And Care
"	W10392126		Not Available	INSTALLATION INSTRUCTION (ENGLISH)
"	W10392127		Not Available	INSTALLATION INSTRUCTION (SPANISH)
2	W10403677			Console Assembly
3	W10388675			Assembly, User Interface
4	8564265			Cover, Rear- User Interface
5	W10211335			Knob, Assembly
6	W10432258			Control Electronic
7	W10112673			Screw, Grommet
8	W10393458			Harness, Wiring Main
9	W10211337			Bracket, Machine Controller
10	W10003770			Screw, 6-19 X 1/2
11	W10185554			Seal, Foam Top
12	8558863			Bracket, Console

13	W10211339		Top
14	W10131402		Screw, 8-18 X 1.370
15	337686	Not Available	SCREW, 8-18 X .500
16	8572039		Seal, User Interface

