

Whirlpool WGD8600YW1 01 - TOP AND CONSOLE PARTS




TOP AND CONSOLE PARTS

For Model: WGD8600YW1

(White)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

12-11 Printed in U.S.A. (BMN) (psw)

1

Part No. W10479384 Rev. A

[Whirlpool Residential Whirlpool WGD8600YW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|-------------|---------------|------------------------------------|
| 1 | W10403269 | | Not Available | TECH SHEET |
| " | W10398830 | | | Guide, Use And Care |
| " | W10392126 | | Not Available | INSTALLATION INSTRUCTION (ENGLISH) |
| 2 | W10403678 | | | Console Assembly |
| 3 | W10388674 | | | Assembly, User Interface |
| 4 | 8564265 | | | Cover, Rear- User Interface |
| 5 | W10211335 | | | Knob, Assembly |
| 6 | W10432258 | | | Control Electronic |
| 7 | 8572039 | | | Seal, User Interface |
| 8 | W10392404 | | | Harness, Wiring |
| 9 | W10211337 | | | Bracket, Machine Controller |
| 10 | W10003770 | | | Screw, 6-19 X 1/2 |
| 11 | W10185554 | | | Seal, Foam Top |
| 12 | 8558863 | | | Bracket, Console |
| 13 | W10211339 | | | Top |
| 14 | W10131402 | | | Screw, 8-18 X 1.370 |

