


# Whirlpool WGD8600YW1 02 - CABINET PARTS

## CABINET PARTS

For Model: WGD8600YW1

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10479384

3

Whirlpool [Residential Whirlpool WGD8600YW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10007520</a>			Clip, Ground
2	<a href="#">8544753</a>			Bracket, Burner
3	<a href="#">3390631</a>			Screw, 10-16 X 3/8
4	<a href="#">8558833</a>			Plate, Cover Terminal Block
5	<a href="#">W10314253</a>			Switch, Assembly Broken Belt
6	<a href="#">W10440460</a>			Cord, Power
7	W10183827	<a href="#">W10223154</a>		Cabinet
8	<a href="#">W10363894</a>			Foot, Dryer
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">8578931</a>			Window, Outer Door
13	<a href="#">8547160</a>			Pulley Assembly
14	<a href="#">W10201446</a>			Bracket-Gas Pipe
16	<a href="#">8571357</a>			Door, Inner
17	<a href="#">W10111888</a>			Plug, Strike

18	<a href="#">W10402478</a>		Handle, Door Cover
19	<a href="#">3394083</a>		Clip, Front Panel
20	8533974	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
21	<a href="#">8579717</a>		Assembly, Hinge
22	<a href="#">3400805</a>		Screw, 8-18 X 3/64
23	<a href="#">8571365</a>		Door, Outer
24	W10111883	<a href="#">W10312757</a>	Panel
25	<a href="#">8558846</a>		Glass, Inner Door
26	<a href="#">3393657</a>		Restrainer, Belt
27	8547170	<a href="#">W10448896</a>	Motordrve
28	<a href="#">W10140148</a>		Panel, Rear
29	<a href="#">8544743</a>		Pulley, Blower
30	<a href="#">8547157</a>		Belt, Drive
31	<a href="#">W10076050</a>		Seal, Window
32	<a href="#">8547158</a>		Bracket, Motor
33	<a href="#">W10111905</a>		Assembly, Door Catch
34	<a href="#">W10401808</a>		Jumper, Door
35	<a href="#">8568303</a>		Locator, Snap Down
36	<a href="#">W10224768</a>		Seal, Foam Spill Guard
37	W10111906	<a href="#">W10295405</a>	Strike
38	<a href="#">W10144494</a>		Plug-Hole
39	W10221653	<a href="#">W10239307</a>	Seal-Door
40	342055	<a href="#">488627</a>	Screw
41	<a href="#">W10318609</a>		Switch, Assembly Door
42	<a href="#">8547171</a>		Pulley,
43	<a href="#">8576625</a>		Lock, Front Top
44	<a href="#">W10044490</a>		Seal, Front Panel
45	<a href="#">8564457</a>		Plug, Front Panel
46	238088	<a href="#">8066217</a>	Hinge, Top
47	<a href="#">W10363887</a>		Riser-Full
48	<a href="#">W10157932</a>		Seal, Foam Cabinet
49	<a href="#">W10215725</a>		Cover, Door Switch
50	<a href="#">308499</a>		Nut-1/4 Hf Self-Thread

