


# Whirlpool WGD9150WW1 02 - CABINET PARTS



Whirlpool [Residential Whirlpool WGD9150WW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8317340</a>			Cover, Terminal Block
2	3390814	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	<a href="#">8565048</a>			Panel, Side
5	W10246525	<a href="#">W10314253</a>		Switch, Assembly Broken Belt
6	3357011	<a href="#">308685</a>		Side Trim )
7	<a href="#">8565054</a>			Panel, Side
8	3392100	<a href="#">49621</a>		Feet-Leveling
NI	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">49252</a>			Plug, Multivent
13	3388672	<a href="#">279640</a>		Pulley-ldr
14	<a href="#">3978776</a>			Bracket, Gas Pipe Switch

15	<a href="#">8565122</a>		Strike, Door
16	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
17	<a href="#">8563727</a>		Bracket, Control
18	<a href="#">W10121334</a>		Washer, Thrust
19	<a href="#">W10318609</a>		Switch, Assembly Door
20	<a href="#">690997</a>		Washer, Thrust
21	8066115	<a href="#">3394331</a>	Plate Cover
22	<a href="#">8580015</a>		Ramp, Door
23	<a href="#">W10235613</a>		Board, Control
24	<a href="#">8580257</a>		Front Panel
25	8533971	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
26	<a href="#">W10085210</a>		Label-Hinge Hole Cover Front Panel
27	8538263	<a href="#">279787</a>	Motor-Drive
28	<a href="#">8565059</a>		Panel, Rear
29	<a href="#">8578220</a>		Pulley, Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">8529757</a>		Bracket, Burner
32	<a href="#">W10242878</a>		Bracket, Motor Mounting
33	3401401	<a href="#">3401402</a>	Cord, Power
34	<a href="#">49026</a>		4" - 90° Elbow
35	<a href="#">693995</a>		Screw, Hex Head
36	<a href="#">3395532</a>		Exhaust Pipe And Bracket
37	<a href="#">3395534</a>		Exhaust Pipe
38	3395535	<a href="#">8563749</a>	Exhaust Pipe
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	<a href="#">8519459</a>		Clip, Toe Panel
41	<a href="#">8540621</a>		Panel, Toe
42	<a href="#">8565046</a>		(BROKEN BELT BASE, CABINET SWITCH)
43	3390647	<a href="#">488729</a>	Screw
44	<a href="#">3387242</a>		Seal, Front Panel
NI	<a href="#">W10331132</a>		Dryer Exhaust Kit

