


Whirlpool WGD9270XR1 05 - DOOR PARTS



Whirlpool [Residential Whirlpool WGD9270XR1 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|---------------|---|
| 1 | W10256915 | | | Label, Hinge Hole Cover |
| 2 | W10304672 | 8578887 | | Door Hinge Assembly |
| 3 | W10215757 | | | Trim, Door Ring Outer |
| " | W10215824 | | | Door Trim Outer Ring |
| " | W10215823 | | | Door Trim Outer Ring |
| 4 | 8534044 | | | Screw, 8-18 X 1/2 |
| 5 | W10215766 | | | Door Trim, Hinge Cover |
| " | W10215826 | | | Door Trim, Hinge Cover |
| " | W10215825 | | | Door Trim, Hinge Cover |
| 6 | 8579663 | | | Seal, Window |
| 7 | 3393258 | 3373329D | | Screw |
| 8 | W10159996 | | | Screw, 10-24 X 25/64 |
| 9 | 8519354 | | | Retainer-Window |
| 10 | W10198441 | W10363674 | | Door Assembly |
| 11 | 355515 | | | Screw, 8-18 X 11/16 |
| 12 | N/P | | Not Available | SCREEN, DOOR (NOT SERVICABLE, ORDER ITEM) |

| | | | |
|----|---------------------------|---------------------------|--|
| | | | 19) |
| 13 | W10286878 | | Window |
| 14 | 690081 | 279570 | Latch |
| 15 | 8519356 | | Retainer-Window |
| 16 | W10215764 | | Door, Intermediate Stationary |
| 17 | 8534022 | | Screw, 8-18 X 1/16 |
| 18 | W10163915 | | Door Seal |
| 19 | W10215762 | W10431338 | Door |
| 20 | N/P | Not Available | TRIM-DOOR INNER RING (NOT SERVICABLE, ORDER ITEM 19) |
| 21 | W10215756 | | Door Assembly Outer |
| " | W10215831 | | Door Assembly Outer |
| " | W10215830 | | Door Assembly Outer |
| 22 | 9742177 | | Screw, 8-18 X .625 |

