



Whirlpool [Residential Whirlpool WGD9270XR1 Dryer Parts](#) Parts Diagram 06 - OPTIONAL PARTS (NOT INCLUDED)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">W10218245</a>			Paint, Touch-Up
"	<a href="#">W10268217</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	8529894	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">8522199</a>			Accessory Parts
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	W10206708	<a href="#">W10044609A</a>		Hose-Kit
"	<a href="#">89503</a>			Hose-Inlet
"	350027	<a href="#">49583</a>		Hose-Fill
"	353362	<a href="#">285452</a>		Hose Screen
"	<a href="#">3357450</a>			Washer, Water Inlet Hose
"	<a href="#">W10269488</a>			Connector- Hose, Y