


Whirlpool WGD9270XW1 05 - DOOR PARTS



Whirlpool [Residential Whirlpool WGD9270XW1 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10256915			Label, Hinge Hole Cover
2	W10304672	8578887		Door Hinge Assembly
3	W10215757			Trim, Door Ring Outer
"	W10215824			Door Trim Outer Ring
"	W10215823			Door Trim Outer Ring
4	8534044			Screw, 8-18 X 1/2
5	W10215766			Door Trim, Hinge Cover
"	W10215826			Door Trim, Hinge Cover
"	W10215825			Door Trim, Hinge Cover
6	8579663			Seal, Window
7	3393258	3373329D		Screw
8	W10159996			Screw, 10-24 X 25/64
9	8519354			Retainer-Window
10	W10198441	W10363674		Door Assembly
11	355515			Screw, 8-18 X 11/16
12	N/P		Not Available	SCREEN, DOOR (NOT SERVICABLE, ORDER ITEM

			19)
13	W10286878		Window
14	690081	279570	Latch
15	8519356		Retainer-Window
16	W10215764		Door, Intermediate Stationary
17	8534022		Screw, 8-18 X 1/16
18	W10163915		Door Seal
19	W10215762	W10431338	Door
20	N/P	Not Available	TRIM-DOOR INNER RING (NOT SERVICABLE, ORDER ITEM 19)
21	W10215756		Door Assembly Outer
"	W10215831		Door Assembly Outer
"	W10215830		Door Assembly Outer
22	9742177		Screw, 8-18 X .625