


# Whirlpool WGD9371YL0 01 - TOP AND CONSOLE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

5-11 Printed in U.S.A. (LT) (psw)

1

Part No. W10416583 Rev. A

Whirlpool Residential Whirlpool WGD9371YL0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10385092		Not Available	USE & CARE GUIDE
"	W10386307		Not Available	TECH SHEET
"	W10385100		Not Available	INSTALLATION INSTRUCTIONS
2	<a href="#">W10336080</a>			Top
"	<a href="#">W10336091</a>			Top
3	<a href="#">W10278758</a>			Harness, Main
4	<a href="#">W10385620</a>			Panel, Console
"	<a href="#">W10385621</a>			Panel, Console
5	<a href="#">8536939</a>			Clip, Knob
6	<a href="#">8565237</a>			Bracket, Console
7	<a href="#">W10006580</a>			Screw, M3-1.12 X12 Pn 6l Spl
8	<a href="#">8572039</a>			Seal, User Interface
9	<a href="#">W10251394</a>			Assembly, Knob White And Silver Models
10	<a href="#">W10381093</a>			Bushing, Shaft Knob
11	3390647	<a href="#">488729</a>		Screw

12	<a href="#">W10266747</a>		Channel-Water, Dryer
13	W10117943	<a href="#">8303811</a>	Badge, Assembly
14	<a href="#">W10387234</a>		Assembly, User Interface
15	<a href="#">W10368266</a>		Window, Led Display

