


Whirlpool WGD9371YW0 02 - CABINET PARTS



Whirlpool [Residential Whirlpool WGD9371YW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8317340			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	8565048			Panel, Side
"	W10251219			Panel, Side
5	W10246525	W10314253		Switch, Assembly Broken Belt
6	343641	681414		Screw, 10AB X 1/2
7	8565054			Panel, Side
"	W10251218			Panel, Side
8	3392100	49621		Feet-Leveling
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	49252			Plug, Multivent

13	3388672	279640	Pulley-ldr
14	3978776		Bracket, Gas Pipe Switch
15	8563727		Bracket, Control
16	8565122		Strike, Door
17	W10281297		Panel, Rear
18	W10121334		Washer, Thrust
19	W10318609		Switch, Assembly Door
20	W10121334		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8580015		Ramp, Door
23	8540621		Panel, Toe
"	W10251210		Toe Panel
24	8572546		Odor Remover
25	3357011	308685	Side Trim)
26	W10317634	W10405846	Control-Elec
27	8538263	279787	Motor-Drve
28	3387242		Seal, Front Panel
29	8578220		Pulley, Motor
30	3387610	661570	Belt
31	8529757		Bracket, Burner
32	W10242878		Bracket, Motor Mounting
33	3401401	3401402	Cord, Power
34	49026		4" - 90° Elbow
35	693995		Screw, Hex Head
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
39	3388674	W10118756	Idler Bracket
40	8519459		Clip, Toe Panel
41	W10085210		Label-Hinge Hole Cover Front Panel
"	W10085230		Label, Hinge Hole Cover
42	8565046		(BROKEN BELT BASE, CABINET SWITCH)
43	3390647	488729	Screw
44	8580257		Front Panel
"	W10251204		Front Panel
NI	W10331132		Dryer Exhaust Kit

