


# Whirlpool WGD9400SW2 01 - TOP AND CONSOLE PARTS



Whirlpool [Residential Whirlpool WGD9400SW2 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

| Item | Original Part Number      | Replaced By               | Status        | Part Description              |
|------|---------------------------|---------------------------|---------------|-------------------------------|
| 1    | W10224575                 |                           | Not Available | USE & CARE GUIDE              |
| "    | W10258369                 |                           | Not Available | TECH SHEET                    |
| "    | W10255469                 |                           | Not Available | INSTALLATION INSTRUCTIONS     |
| 2    | 3980634                   | <a href="#">W10117263</a> |               | Top                           |
| 3    | <a href="#">W10111062</a> |                           |               | Harness, Main                 |
| 4    | <a href="#">W10246730</a> |                           |               | Panel, Console And 31)        |
| 5    | <a href="#">3394427</a>   |                           |               | Clip-Harness                  |
| 6    | <a href="#">W10215656</a> |                           |               | Bracket, Console              |
| 7    | <a href="#">353424</a>    |                           |               | Plug, Terminal                |
| 8    | <a href="#">94614</a>     |                           |               | Terminal                      |
| 9    | <a href="#">3936144</a>   |                           |               | Do-It-Yourself Repair Manuals |
| 10   | 94613                     | <a href="#">596797</a>    |               | Terminal                      |
| 11   | 3390647                   | <a href="#">488729</a>    |               | Screw                         |
| 12   | <a href="#">W10112267</a> |                           |               | Foam-Seal Control Bracket     |
| 13   | W10030070                 | <a href="#">W10012480</a> |               | Kit                           |
| 14   | <a href="#">3936150</a>   |                           |               | Connector, 7-Circuit          |

|    |                           |                           |                            |
|----|---------------------------|---------------------------|----------------------------|
| 15 | <a href="#">3395683</a>   |                           | Receptacle, Multi-Terminal |
| 17 | <a href="#">2203186</a>   |                           | Connector, 5-Circuit       |
| 18 | W10246782                 | <a href="#">W10294634</a> | Kit                        |
| 19 | <a href="#">W10121375</a> |                           | User Interface             |
| 20 | <a href="#">W10012430</a> |                           | Encoder, Wheel Kit.        |
| 21 | <a href="#">W10012440</a> |                           | Retainer-Snap              |
| 22 | <a href="#">W10012410</a> |                           | Knob, Light Ring           |
| 23 | W10012810                 | <a href="#">280230</a>    | Encoder, Wheel Kit.        |
| 24 | W10012460                 | <a href="#">280230</a>    | Encoder, Wheel Kit.        |
| 25 | <a href="#">W10242906</a> |                           | Harness, Communication     |
| 26 | W10012820                 | <a href="#">280230</a>    | Encoder, Wheel Kit.        |
| 27 | <a href="#">W10116702</a> |                           | Knob, Control              |
| 28 | <a href="#">280230</a>    |                           | Encoder, Wheel Kit.        |
| 29 | <a href="#">W10112268</a> |                           | Clip-Harness               |
| 30 | <a href="#">3391018</a>   |                           | Tie Cable                  |
| 31 | W10117943                 | <a href="#">8303811</a>   | Badge, Assembly            |

