


# Whirlpool WGD9470WW3 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

GAS DRYER

For Model: WGD9470WW3  
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3-12 Litho In U.S.A. (BMN)(bay)

1

Part No. W10494221 Rev. A

Whirlpool [Residential Whirlpool WGD9470WW3 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10477028		Not Available	USE & CARE GUIDE
"	W10298850		Not Available	TECH SHEET
"	W10471645		Not Available	INSTALLATION, INSTRUCTION
2	3980634	<a href="#">W10117263</a>		Top
3	<a href="#">W10111069</a>			Harness, Main
4	<a href="#">W10255229</a>			Panel, Console
5	<a href="#">3391018</a>			Tie Cable
6	<a href="#">W10215656</a>			Bracket, Console
7	<a href="#">W10112268</a>			Clip-Harness
8	W10117943	<a href="#">8303811</a>		Badge, Assembly
9	<a href="#">489463</a>			Screw, 8-18 X 1/16
10	<a href="#">W10112267</a>			Foam-Seal Control Bracket
11	W10030070	<a href="#">W10012480</a>		Kit
12	<a href="#">693995</a>			Screw, Hex Head
13	<a href="#">W10279773</a>			User Interface
14	<a href="#">W10279709</a>			User Interface,

15	<a href="#">W10012430</a>		Encoder, Wheel Kit.
16	<a href="#">W10012440</a>		Retainer-Snap
17	<a href="#">W10250089</a>		Knob, Light Ring
18	W10006660	Not Available	RAST, WHEEL ASSY. (SERVICE ONLY WITH ITEM. 24)
19	<a href="#">W10012480</a>		Kit
20	<a href="#">W10242906</a>		Harness, Communication
21	W10012820	<a href="#">280230</a>	Encoder, Wheel Kit.
22	<a href="#">W10190685</a>		Knob, Control
23	W10133763	Not Available	DETENT WHEEL (SERVICE ONLY WITH ILLUS. 28 )

**Howes**  
the laundry company®

**Howes**  
the laundry company®

**Howes**  
the laundry company®