


Whirlpool WGD94HEXR2 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: WGD94HEXW2, WGD94HEXR2, WGD94HEXL2
(White) (Red) (Silver)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3-12 Litho in U.S.A. (JLP)(bay)

1

Part No. W10486821 Rev. A

Whirlpool [Residential Whirlpool WGD94HEXR2 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305730		Not Available	USE & CARE GUIDE (ENGLISH)
"	W10420005		Not Available	TECH SHEET
"	W10423115		Not Available	INSTALLATION, INSTRUCTION
2	W10208383			Top
"	W10337792			Top
"	W10316282			Top
3	W10441591			Harness, Main
4	W10464682			Panel, Console
"	W10464684			Panel, Console
"	W10464683			Panel, Console
5	W10317570			Water Channel
6	W10208198			Bracket, Console
7	W10267938			Harness, UI Jumper
8	W10267937			Harness, Jumper
9	W10117943	8303811		Badge, Assembly

10

[693995](#)

Screw, Hex Head

11

3390647

[488729](#)

Screw

12

[W10317566](#)

Spring, Clip Water Channel

