


# Whirlpool WGD94HEXW2 02 - CABINET PARTS



Whirlpool [Residential Whirlpool WGD94HEXW2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8317339</a>			Cover, Terminal Block
2	<a href="#">3390631</a>			Screw, 10-16 X 3/8
3	8533974	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	<a href="#">W10469589</a>			Panel, Side
"	<a href="#">W10469590</a>			Panel, Side
"	<a href="#">W10469592</a>			Panel, Side
5	<a href="#">W10411936</a>			Switch, Broken Belt
6	3357011	<a href="#">308685</a>		Side Trim )
7	<a href="#">W10468495</a>			Panel, Side
"	<a href="#">W10468502</a>			Panel, Side
"	<a href="#">W10468499</a>			Panel, Side
8	3392100	<a href="#">49621</a>		Feet-Leveling
NI	<a href="#">279810</a>			Foot-Optional
9	<a href="#">W10121316</a>			Plug, Multivent
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16

12	<a href="#">W10404617</a>		Plug, Multivent
13	3388672	<a href="#">279640</a>	Pulley-Ildr
14	<a href="#">3978776</a>		Bracket, Gas Pipe Switch
15	<a href="#">W10288126</a>		Screw, 10-32 X 1/2
16	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">W10121334</a>		Washer, Thrust
19	<a href="#">W10267834</a>		Door Switch Assembly
20	<a href="#">690997</a>		Washer, Thrust
21	<a href="#">W10354249</a>		Plate, Cover
22	<a href="#">W10208218</a>		Bracket, Door Hinge
23	<a href="#">W10208250</a>		Strike, Door
24	<a href="#">693995</a>		Screw, Hex Head
25	<a href="#">3387242</a>		Seal, Front Panel
26	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
27	8538263	<a href="#">279787</a>	Motor-Drve
28	<a href="#">8565046</a>		(BROKEN BELT BASE, CABINET SWITCH)
29	<a href="#">8578220</a>		Pulley, Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">8529757</a>		Bracket, Burner
32	<a href="#">W10242878</a>		Bracket, Motor Mounting
33	W10440461	<a href="#">3401402</a>	Cord, Power
34	W10416072	Not Available	4" - 90° ELBOW
35	<a href="#">W10208382</a>		Bracket, Rear Dryer
36	<a href="#">8563747</a>		Exhaust Pipe Medium Pipe
37	<a href="#">W10331278</a>		Exhaust Pipe
38	<a href="#">8563749</a>		Exhaust Pipe
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	<a href="#">W10378252</a>		Control Board
41	<a href="#">W10259611</a>		Bracket, Control
42	3390647	<a href="#">488729</a>	Screw
43	<a href="#">W10208192</a>		Front Panel
"	<a href="#">W10337783</a>		Front Panel
"	<a href="#">W10316296</a>		Front Panel
44	<a href="#">W10247569</a>		Panel, Rear
45	<a href="#">8564457</a>		Plug, Front Panel
"	<a href="#">W10256411</a>		Plug, Front Panel
"	<a href="#">W10249704</a>		Plug, Front Panel
NI	<a href="#">W10323246</a>		Dryer Exhaust Kit

*the laundry company®*