


**Whirlpool WGD9500TC0 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)**



W10163339

9

Whirlpool [Residential Whirlpool WGD9500TC0 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10085210</a>			Label-Hinge Hole Cover Front Panel
2	<a href="#">W10139920</a>			Door Hinge Assembly
3	W10017850	<a href="#">280203</a>		Screw-Kit
4	<a href="#">9742177</a>			Screw, 8-18 X .625
5	<a href="#">W10048910</a>			Screw-Plug
6	<a href="#">W10139457</a>			Seal-Door Handle, Ring Door
7	<a href="#">8579502</a>			Handle, Door
"	<a href="#">8579503</a>			HANdle-Ring And Pad Assembly
8	3393008	<a href="#">308685</a>		Side Trim )
9	8579520	<a href="#">W10180115</a>		Door Assembly
"	8579521	<a href="#">W10180116</a>		Door Assembly
10	<a href="#">8578229</a>			Door Assembly
11	<a href="#">355515</a>			Screw, 8-18 X 11/16

12	3398175	<a href="#">279570</a>	Latch
13	<a href="#">8519356</a>		Retainer-Window
14	<a href="#">8519354</a>		Retainer-Window
15	<a href="#">8579662</a>		Gasket, Window
16	8578153	<a href="#">W10180119</a>	Cover-Hinge, Stationary Cover Hinge
"	BLANK	Not Available	(Following Parts Not Included)
"	8578152	<a href="#">W10181197</a>	Cover Hinge
17	<a href="#">8566254</a>		Glass-Window
18	690081	<a href="#">279570</a>	Latch
19	W10139333	<a href="#">W10180488</a>	Tear-Drop Trim And Clip Assembly
"	W10133746	<a href="#">W10180506</a>	Tear-Drop Trim And Clip Assembly
20	W10074630	<a href="#">W10180120</a>	Shield, Door
21	8578157	<a href="#">W10180118</a>	Door, Intermediate
22	<a href="#">8578156</a>		Door Mask
23	<a href="#">8578155</a>		Door Screen
24	3393258	<a href="#">3373329D</a>	Screw
	<a href="#">72017</a>		Paint, Touch-Up
"	W10152090	Not Available	PAINT, TOUCH-UP (1/2oz.) (Chestnut)
"	<a href="#">8212605</a>		Paint, Pressurized Spray
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	<a href="#">346764</a>	Kit, Hold Down
"	8579666A	<a href="#">W10466829</a>	Blade
"	<a href="#">8541503</a>		Kit, Stack Assembly
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8521957	<a href="#">W10121663</a>	Dryer Rack
"	BLANK	Not Available	Following Parts Not Illustrated
"	<a href="#">76314</a>		Hose, Inlet 6 Ft. Hose With Elbow
"	<a href="#">W10044603</a>		Connector, Hose ``Y``
"	3976300	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	W10044604	<a href="#">49586</a>	Mixer

*the laundry company*<sup>®</sup>