


# Whirlpool WGD9500TU1 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Models: WGD9500TW1, WGD9500TC1, WGD9500TU1  
(White) (Chestnut) (Ultimate Silver)

GAS DRYER



3-08 LITHO IN U.S.A. (LAN)

1

Part No. W10190382 Rev. A

Whirlpool [Residential Whirlpool WGD9500TU1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10122320		Not Available	Use & Care Guide
"	W10177456		Not Available	Tech Sheet
"	W10139322		Not Available	TIP SHEET DRYER STEAM
"	W10122321		Not Available	Guide, Quick Start
2	8519251	<a href="#">W10117263</a>		Top
"	<a href="#">W10140291</a>			Top
"	<a href="#">W10114785</a>			Top
3	<a href="#">W10181775</a>			Harness, Main
4	<a href="#">W10153649</a>			Panel, Console
"	<a href="#">W10177358</a>			Panel, Console
"	<a href="#">W10133748</a>			Panel, Console
5	<a href="#">3391018</a>			Tie Cable
6	W10006840	<a href="#">W10215656</a>		Bracket, Console
7	<a href="#">W10112268</a>			Clip-Harness
8	<a href="#">94614</a>			Terminal
9	<a href="#">3936144</a>			Do-It-Yourself Repair Manuals

10	W10117943	<a href="#">8303811</a>	Badge, Assembly
11	3390647	<a href="#">488729</a>	Screw
12	<a href="#">W10112267</a>		Foam-Seal Control Bracket
13	W10030070	<a href="#">W10012480</a>	Kit
14	<a href="#">3936150</a>		Connector, 7-Circuit
15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	98139	<a href="#">303776</a>	Screw
17	<a href="#">2203186</a>		Connector, 5-Circuit
18	W10137338	<a href="#">W10294630</a>	Kit
19	<a href="#">W10121375</a>		User Interface
20	<a href="#">W10012430</a>		Encoder, Wheel Kit.
21	<a href="#">W10012440</a>		Retainer-Snap
22	<a href="#">W10012410</a>		Knob, Light Ring
23	W10012810	<a href="#">280230</a>	Encoder, Wheel Kit.
24	W10012460	<a href="#">280230</a>	Encoder, Wheel Kit.
25	<a href="#">W10095960</a>		Harness, Communication
26	W10012820	<a href="#">280230</a>	Encoder, Wheel Kit.
27	<a href="#">W10116702</a>		Knob, Control
"	<a href="#">W10153664</a>		Knob, Control
"	<a href="#">W10116704</a>		Knob, Control
28	<a href="#">280230</a>		Encoder, Wheel Kit.
29	<a href="#">W10111020</a>		Power Cable, User-Interface

