


Whirlpool WGD9500TW0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: WGD9500TW0, WGD9500TC0
(White) (Chestnut)

GAS DRYER



12-07 LITHO IN U.S.A. (LT)

1

Part No. W10163339 Rev. A

Whirlpool Residential Whirlpool WGD9500TW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10122320		Not Available	Use & Care Guide
"	W10050531		Not Available	Tech Sheet
"	W10139322		Not Available	TIP SHEET DRYER STEAM
"	W10122321		Not Available	Guide, Quick Start
2	8519251	W10117263		Top
"	W10140291			Top
3	W10110985			Harness, Main
4	W10153649			Panel, Console
"	W10177358			Panel, Console
5	3391018			Tie Cable
6	W10006840	W10215656		Bracket, Console
7	W10112268			Clip-Harness
8	94614			Terminal
9	3936144			Do-It-Yourself Repair Manuals
10	94613	596797		Terminal
11	3390647	488729		Screw

12	W10112267		Foam-Seal Control Bracket
13	W10030070	W10012480	Kit
14	3936150		Connector, 7-Circuit
15	3395683		Receptacle, Multi-Terminal
16	8281225		Screw, 8-18 X 1/2
17	2203186		Connector, 5-Circuit
18	W10137338	W10294630	Kit
19	W10121375		User Interface
20	W10012430		Encoder, Wheel Kit.
21	W10012440		Retainer-Snap
22	W10012410		Knob, Light Ring
23	W10012810	280230	Encoder, Wheel Kit.
24	W10012460	280230	Encoder, Wheel Kit.
25	W10095960		Harness, Communication
26	W10012820	280230	Encoder, Wheel Kit.
27	W10116702		Knob, Control
"	W10153664		Knob, Control
28	280230		Encoder, Wheel Kit.
29	W10117943	8303811	Badge, Assembly
30	W10110976		Cube, Cable

