


Whirlpool WGD9500TW0 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)



W10163339

9

Whirlpool [Residential Whirlpool WGD9500TW0 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10085210			Label-Hinge Hole Cover Front Panel
2	W10139920			Door Hinge Assembly
3	W10017850	280203		Screw-Kit
4	9742177			Screw, 8-18 X .625
5	W10048910			Screw-Plug
6	W10139457			Seal-Door Handle, Ring Door
7	8579502			Handle, Door
"	8579503			HANdle-Ring And Pad Assembly
8	3393008	308685		Side Trim)
9	8579520	W10180115		Door Assembly
"	8579521	W10180116		Door Assembly
10	8578229			Door Assembly
11	355515			Screw, 8-18 X 11/16

12	3398175	279570	Latch
13	8519356		Retainer-Window
14	8519354		Retainer-Window
15	8579662		Gasket, Window
16	8578153	W10180119	Cover-Hinge, Stationary Cover Hinge
"	BLANK	Not Available	(Following Parts Not Included)
"	8578152	W10181197	Cover Hinge
17	8566254		Glass-Window
18	690081	279570	Latch
19	W10139333	W10180488	Tear-Drop Trim And Clip Assembly
"	W10133746	W10180506	Tear-Drop Trim And Clip Assembly
20	W10074630	W10180120	Shield, Door
21	8578157	W10180118	Door, Intermediate
22	8578156		Door Mask
23	8578155		Door Screen
24	3393258	3373329D	Screw
	72017		Paint, Touch-Up
"	W10152090	Not Available	PAINT, TOUCH-UP (1/2oz.) (Chestnut)
"	8212605		Paint, Pressurized Spray
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down
"	8579666A	W10466829	Blade
"	8541503		Kit, Stack Assembly
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8521957	W10121663	Dryer Rack
"	BLANK	Not Available	Following Parts Not Illustrated
"	76314		Hose, Inlet 6 Ft. Hose With Elbow
"	W10044603		Connector, Hose ``Y``
"	3976300	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	W10044604	49586	Mixer

the laundry company[®]