


Whirlpool WGD95HEXW0 01 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool WGD95HEXW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305730		Not Available	USE & CARE GUIDE (ENGLISH)
"	W10306459		Not Available	USE & CARE GUIDE (TECH SHEET INSTALLATION, INSTRUCTION)
"	W10057364		Not Available	INSTALLATION INSTRUCTIONS
2	W10208383			Top
"	W10337792			Top
"	W10316282			Top
3	W10267282	W10355891		Harness, Main
4	W10352457			Panel, Console Assembly
"	W10352461			Panel, Console Assembly
"	W10352459			Panel, Console Assembly
5	W10317570			Water Channel
6	W10208198			Bracket, Console
7	W10267937			Harness, Jumper
8	W10267938			Harness, UI Jumper

9	W10117943	8303811	Badge, Assembly
10	693995		Screw, Hex Head
11	3390647	488729	Screw
12	W10267833		Cable, Led User-Interface
13	W10317566		Spring, Clip Water Channel

