


# Whirlpool WGD9600SU0 02 - CABINET PARTS



W10118307

3

Whirlpool [Residential Whirlpool WGD9600SU0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8317340</a>			Cover, Terminal Block
2	3390814	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	W10095480	<a href="#">W10117287</a>		Panel
5	3394881	<a href="#">279782</a>		Switch-Lid
6	3357011	<a href="#">308685</a>		Side Trim )
7	W10095440	<a href="#">W10117286</a>		Panel
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	697750	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	3388309	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	<a href="#">3388311</a>			Plug, Multivent

"	8579115	<a href="#">W10117271</a>		Top
13	3388672	<a href="#">279640</a>		Pulley-ldr
14	<a href="#">3978776</a>			Bracket, Gas Pipe Switch
15	<a href="#">8066120</a>			Lever, Door Switch
16	<a href="#">3394081</a>			Wire, Broken Belt Switch
17	8564132	<a href="#">8564134</a>		Board, Sound Dampening
18	<a href="#">233520</a>			Washer, Thrust
19	8574875	<a href="#">W10318609</a>		Switch, Assembly Door
20	<a href="#">690997</a>			Washer, Thrust
21	8066115	<a href="#">3394331</a>		Plate Cover
22	<a href="#">8529053</a>			Ramp, Door Door Switch
23	<a href="#">3407228</a>			Assembly, Power Cube
24	<a href="#">693995</a>			Screw, Hex Head
27	8538263	<a href="#">279787</a>		Motor-Drve
28	<a href="#">3398948</a>			Wire, Jumper
29	<a href="#">8578220</a>			Pulley, Motor
30	3387610	<a href="#">661570</a>		Belt
31	<a href="#">8529757</a>			Bracket, Burner
32	<a href="#">3387118</a>			Bracket, Motor
33	3401401	<a href="#">3401402</a>		Cord, Power
34	<a href="#">49026</a>			4" - 90° Elbow
36	<a href="#">8563747</a>			Exhaust Pipe Medium Pipe
37	<a href="#">8563750</a>			Exhaust Pipe
38	<a href="#">8563749</a>			Exhaust Pipe
39	3388674	<a href="#">W10118756</a>		Idler Bracket
42	<a href="#">98129</a>			Screw, 6-20 X 1 1/16
43	3390647	<a href="#">488729</a>		Screw
44	<a href="#">3387242</a>			Seal, Front Panel
45	3393008	<a href="#">308685</a>		Side Trim )
46	<a href="#">8519459</a>			Clip, Toe Panel
50	<a href="#">8519207</a>			Base, Cabinet
51	<a href="#">8578940</a>			Front Panel
52	696144	<a href="#">279570</a>		Latch
55	8579736	<a href="#">W10181464</a>		Harness, Digital Interface
56	<a href="#">8563727</a>			Bracket, Control
57	<a href="#">W10110641</a>			Board, Control
59	<a href="#">3400826</a>			Screw, 8-18 X 3/4
61	<a href="#">W10116277</a>			Toe, Panel
62	8519219	<a href="#">280036</a>		Panel-Rear
63	<a href="#">692400</a>			Nut, Push-In
64	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
"	BLANK		Not Available	Optional Parts Not Included
66	279818	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	279820	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	279925	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	280171	<a href="#">W10470674</a>		Dryer Exhaust Kit