


Whirlpool WGD9600TU0 02 - CABINET PARTS



W10149459

3

Whirlpool Residential Whirlpool WGD9600TU0 Dryer Parts Parts Diagram 02 - CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8317340			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	W10139003	W10117273		Panel
"	W10139013	W10156774		Panel
"	W10139009	W10117287		Panel
"	W10139010	W10117283		Panel
"	W10095480	W10117287		Panel
5	3394881	279782		Switch-Lid
6	3357011	308685		Side Trim)
7	W10138989	W10117272		Panel
"	W10138999	W10156768		Panel
"	W10138995	W10117286		Panel
"	W10138996	W10117282		Panel
8	3392100	49621		Feet-Leveling
"	279810			Foot-Optional

9	660658		Clamp, Motor Mounting 343481 685441
10	3387374		Spring, Idler
11	3389420		Retainer-Idler 1/4-20 X 1/16
12	697750	W10470674	Dryer Exhaust Kit
"	W10136987		Plug, Multivent
"	8579117		Plug, Multivent
"	3388309	W10470674	Dryer Exhaust Kit
13	3388672	279640	Pulley-Idr
14	3978776		Bracket, Gas Pipe Switch
15	8066120		Lever, Door Switch
16	3394081		Wire, Broken Belt Switch
17	W10128772	8564134	Board, Sound Dampening
18	233520		Washer, Thrust
19	W10128087	W10318609	Switch, Assembly Door
20	W10121334		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8529053		Ramp, Door Door Switch
23	W10118614		Seal, Door Switch
24	693995		Screw, Hex Head
25	W10118470		Cover, Bracket Control
26	3407228		Assembly, Power Cube
27	8538263	279787	Motor-Drve
28	3398948		Wire, Jumper
29	8578220		Pulley, Motor
30	3387610	661570	Belt
31	8529757		Bracket, Burner
32	3387118		Bracket, Motor
33	3401401	3401402	Cord, Power
34	49026		4" - 90° Elbow
35	3389682		Space-Toe Panel User-Interface
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
39	3388674	W10118756	Idler Bracket
40	62825		Clip-S Type Control Board
42	98129		Screw, 6-20 X 1 1/16
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3393008	308685	Side Trim)
46	8519459		Clip, Toe Panel
50	8519207		Base, Cabinet
51	8578388		Front Panel
"	W10140574		Front Panel
"	8578940		Front Panel
"	8578936		Front Panel
52	696144	279570	Latch
55	8579736	W10181464	Harness, Digital Interface
56	8563727		Bracket, Control
57	W10141671		Board, Control
59	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

60	W10116271	W10246269	Panel, Toe
"	W10140572		Toe Panel
"	W10116277		Toe, Panel
"	W10116273		Toe Panel
61	W10116475		Panel, Rear
62	343641	681414	Screw, 10AB X 1/2
"	BLANK		Not Available
			Optional Parts Not Included
64	279818	W10470674	Dryer Exhaust Kit
"	279820	W10470674	Dryer Exhaust Kit
"	W10152954	W10470674	Dryer Exhaust Kit
"	280171	W10470674	Dryer Exhaust Kit

