


Whirlpool WGD9610XW1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

27" GAS DRYER

For Model: WGD9610XW1
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3-12 Litho In U.S.A. (BMN)(bay)

1

Part No. W10492252 Rev. A

[Whirlpool Residential Whirlpool WGD9610XW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10477028		Not Available	USE & CARE GUIDE
"	W10298850		Not Available	TECH SHEET
"	W10471645		Not Available	INSTALLATION, INSTRUCTION
2	3980634	W10117263		Top
3	W10111069			Harness, Main
4	W10255229			Panel, Console
5	3391018			Tie Cable
6	W10215656			Bracket, Console
7	W10112268			Clip-Harness
8	W10117943	8303811		Badge, Assembly
9	W10012480			Kit
10	W10190685			Knob, Control
11	3390647	488729		Screw
12	W10112267			Foam-Seal Control Bracket
13	W10030070	W10012480		Kit
14	W10012820	280230		Encoder, Wheel Kit.

15	W10242906		Harness, Communication
16	W10012810	280230	Encoder, Wheel Kit.
17	W10133763	Not Available	DETENT WHEEL (SERVICE ONLY WITH ILLUS. 28)
18	W10279773		User Interface
19	W10279709		User Interface,
20	W10012430		Encoder, Wheel Kit.
21	W10012440		Retainer-Snap
22	W10250089		Knob, Light Ring

