



Whirlpool [Residential Whirlpool WGD97HEXL0 Dryer Parts](#) Parts Diagram 06 - OPTIONAL PARTS (NOT INCLUDED)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">W10268217</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	<a href="#">786032</a>			Refinishing Material
"	8529894	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">W10323246</a>			Dryer Exhaust Kit
"	<a href="#">W10298318RP</a>			Paint, Bulk
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	<a href="#">W10322470A</a>			Paint, Bulk
"	W10206708	<a href="#">W10044609A</a>		Hose-Kit
"	<a href="#">89503</a>			Hose-Inlet
"	353362	<a href="#">285452</a>		Hose Screen
"	350027	<a href="#">49583</a>		Hose-Fill
				Washer Inlet-Hose

" W10242307

[16123](#)

Miscellaneous Parts Must be  
Ordered Separately.

" W10044604

[49586](#)

Mixer

