


Whirlpool WGD97HEXL1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: WGD97HEXW1, WGD97HEXR1, WGD97HEXL1
(White) (Red) (Silver)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

7-11 Litho in U.S.A. (L.T.) (eeb)

1

Part No. W10431374 Rev. A

[Whirlpool Residential Whirlpool WGD97HEXL1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305728		Not Available	USE & CARE GUIDE
"	W10319757		Not Available	TECH SHEET
"	W10423115		Not Available	INSTALLATION, INSTRUCTION
2	W10208383			Top
"	W10337792			Top
"	W10316282			Top
3	W10357657			Harness, Main
4	W10352483		Not Available	PANEL, CONSOLE ASSEMBLY (INCLUDE ITEMS, 7,8,9,10,13, 14,15 & 16) (WHITE)
"	W10352485			Panel, Console Assembly
"	W10352484			Panel, Console Assembly
5	W10317570			Water Channel
6	W10208198			Bracket, Console
7	W10267938			Harness, UI Jumper
8	W10267937			Harness, Jumper

9	W10117943	8303811	Badge, Assembly
10	W10317566		Spring, Clip Water Channel
11	3390647	488729	Screw
12	W10267832		Cable, User Interface
13	693995		Screw, Hex Head

