



Whirlpool [Residential Whirlpool WGD97HEXR2 Dryer Parts](#) Parts Diagram 06 - OPTIONAL PARTS (NOT INCLUDED)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	72017			Paint, Touch-Up
"	W10363227			Paint, Touch-Up
"	W10268217			Paint, Touch-Up
"	350930			Paint, Pressurized Spray B
"	350938			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	786032			Refinishing Material
"	8529894	346764		Kit, Hold Down
"	W10323246			Dryer Exhaust Kit
"	W10298318RP			Paint, Bulk
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	W10322470A			Paint, Bulk
"	W10206708	W10044609A		Hose-Kit
"	89503			Hose-Inlet
"	353362	285452		Hose Screen
"	350027	49583		Hose-Fill

"	3357450	Washer, Water Inlet Hose
"	W10242307	16123 Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	W10269488	Connector- Hose, Y

