


Whirlpool WGT3300SQ2 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

DRYER SUPPORT AND WASHER HARNESS PARTS

For Model: WGT3300SQ2
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10259010

7

Whirlpool [Residential Whirlpool WGT3300SQ2 Washer/Dryer Parts](#) Parts Diagram 05 - DRYER SUPPORT AND WASHER HARNESS PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10139637			Harness - Washer
"	3350130			Plug, Terminal
"	3347243			Block, Disconnect
"	352089			Timer, Block Disconnect
"	3350211		Not Available	Receptacle, 3 Way
"	62505			Block, Disconnect
2	3388851			Channel Assembly
3	3388850			Channel Assembly
4	3390609			Shield, Harness
5	8545438			Hose, Pressure Switch
6	W10210799			Clip, Harness
7	343641	681414		Screw, 10AB X 1/2
8	63523			Harness, Protector
9	94613	596797		Terminal
"	94614			Terminal

10	3360056		Connector
11	3400300	Y015627	Screw- Hex
12	8533952		Nut, Hex
13	3392232		Shield, Front
14	3390336		Shield, Thermostat
15	3391249		Cable Tie, Push Mount
16	3354925		Block, Connector

