



**NON – ILLUSTRATED
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Whirlpool Residential Whirlpool WGT3300XQ1 Washer/Dryer Parts Parts Diagram 16 - OPTIONAL PARTS (NOT INCLUDED)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	72017			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	350572			Oil
"	285208			Lubricant
"	285195			Sealer Sealer, Gasket
"	3391335	279823		Side Exhaust Extension Kit