


Whirlpool WTW4850XQ1 04 - GEARCASE, MOTOR AND PUMP PARTS

GEARCASE, MOTOR AND PUMP PARTS

For Model: WTW4850XQ1
(White)



Whirlpool [Residential Whirlpool WTW4850XQ1 Washer Parts](#) Parts Diagram 04 - GEARCASE, MOTOR AND PUMP PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10276397			Pump Assembly, Drain
2	W10004910			Screw, 12-16 X 1-1/4
3	W10215091			Hose, Inner Drain Assembly
4	8317496	285655		Clamp, Hose
5	W10006378	W10473144		Gearcase Assembly
6	W10249633			Screw, 7.2-1.6 X 30
7	W10006357	W10303798		Motor-Drive
8	W10094780	W10182109		Screw-Kit
9	W10006382	W10315818		Cam
10	W10006352	W10315818		Cam
11	W10006353	W10315818		Cam
12	W10006354	W10315818		Cam
13	W10006356			Pulley
14	W10163336			Nut, Pulley
15	W10006384			Belt, Drive
16	W10006355			Actuator, Shift

17	9741052	Screw, 6-32 X 1.00
18	W10278556	Capacitor, Motor Run
19	357640	Screw And Washer
20	W10006383	Shield, Pulley Cover

