


Whirlpool WTW4930XW0 02 - CONTROLS AND WATER INLET PARTS

CONTROLS AND WATER INLET PARTS

For Model: WTW4930XW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10371182

3

Whirlpool [Residential Whirlpool WTW4930XW0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND WATER INLET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10338629			Panel, Console
2	8536939			Clip, Knob
3	8566035	8565957		Cap, End
4	8566032	8565954		Cap, End
5	8312709			Clip-Console
6	W10296033	W10393841		Control-Elec
7	W10251310	W10420985		Panel, Console Rear Cover
8	1157158	489069		Xxscrew, 10-12 X 1/2
9	W10268912			Switch, Water Level
10	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
11	W10276649			Cord, Power
12	3400076			Screw, Bracket Mounting
13	W10034750			Timer Knob Assembly
14	W10034380			Knob, Control
15	W10285512			Switch, Rotary Encoder

16	W10291174		Harness, Upper
17	W10334612	W10432353	Inlet Assembly, Water
18	W10337338	W10356257	Valve, Water Mixing
19	W10334611	W10441423	Vacuum Break
20	W10238347		Hose, Vacuum Break
21	W10117298	596669	Clamp, Manifold
22	W10337345	W10344775	Harness, Valve
23	8281163		Screw, Dispenser Housing Mounting
24	W10240973		Foam, Ivvb
25	W10348582		Cable Tie

