


# Whirlpool WTW4930XW0 03 - BASKET AND TUB PARTS



Whirlpool [Residential Whirlpool WTW4930XW0 Washer Parts](#) Parts Diagram 03 - BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8575076	<a href="#">8575076A</a>		Dispenser
2	3354733	<a href="#">W10074580</a>		Cap, Barrier
3	<a href="#">W10072840</a>			Fabric Softener
4	<a href="#">W10003790</a>			Screw And Washer
5	<a href="#">3949550</a>			Washer
6	<a href="#">3951744</a>			Agitator Assembly
7	3951682	<a href="#">285809</a>		Cam-Agitator
8	3366877	<a href="#">80040</a>		Dog-Agitator
9	<a href="#">3952374</a>			Bearing, Driven Cam
10	<a href="#">3363003</a>			Mover, Clothes
11	<a href="#">3951608</a>			Spacer, Thrust
12	<a href="#">3951632</a>			Agitator
13	<a href="#">W10215108</a>			Ring, Tub
14	<a href="#">21366</a>			Nut, Spanner
15	W10238308	<a href="#">W10349185</a>		Basket
16	<a href="#">389140</a>			Tub Block, Basket Drive

17	<a href="#">W10339098</a>		Shield, Splash
18	W10238320	<a href="#">W10371566</a>	Tub-Outer
19	W10006371	<a href="#">W10324647</a>	Seal-Tub
20	<a href="#">W10215093</a>		Filter, Drain Pump
21	<a href="#">8533928</a>		Screw, 8-18 X 3/4
22	W10257088	<a href="#">W10349191</a>	Suspension
23	W10215136	<a href="#">W10440729</a>	Suspension
24	W10256551	<a href="#">W10440729</a>	Suspension
25	W10276648	<a href="#">W10297444</a>	Harness, Lower
26	W10297436	<a href="#">353244</a>	Hose, Pressure Switch
27	<a href="#">W10005430</a>		Clamp, Pressure Hose Retainer
28	8533943	<a href="#">W10109200</a>	Screw, Baffle Mounting
29	<a href="#">W10298887</a>		Cable Tie

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>