


Whirlpool WTW5300VW1 02 - CONTROLS AND REAR PANEL PARTS



W10236852

3

Whirlpool [Residential Whirlpool WTW5300VW1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10044160			Wiring Harness
2	9740848			Screw, Mixing Valve Mounting
3	3347868	W10339879		Tie, Cable
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	W10194449			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	8577356			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577843	W10337781		Switch-WL
13	8566003			Bracket, Control
14	8578842	285800		Cord-Power

15	3952821	285777	Relief-Str
16	8566035	8565957	Cap, End
17	8566032	8565954	Cap, End
18	3979347	3979346	Valve, Water Inlet And Thermistor Assembly
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	301958	596669	Clamp, Manifold
22	W10190501		Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	W10190514		Break, Vacuum
25	8318046		Clip, Capacitor
26	8519200		Support, Rear Panel
27	W10184148		Switch, Water Temperature
28	3949187	W10168262	Switch, Rotary
29	8572717		Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
34	3400818		Screw, Timer Mounting
35	W10196930		Panel, Console
36	W10034730		Knob, Timer
37	8566018		Dial,
38	W10034380		Knob, Control
39	8536939		Clip, Knob
40	8312709		Clip-Console
41	8314879		Shield, Inlet Valve
42	8055003		Clip, Harness And Pressure Switch

