


Whirlpool WTW5310SQ0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: WTW5310SQ0
(White)



6161321

5

Whirlpool [Residential Whirlpool WTW5310SQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
3	3949550			Washer
4	63235			Agitator Assembly
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	21366			Nut, Spanner
8	8526017	W10389329		Clothes Container, Assembly
9	8519788	387240		Ring, Balance
10	2219077			Clip, Pressure Switch Hose
11	63849			Strain Relief, Power Cord
12	389140			Tub Block, Basket Drive
13	383727			Gasket, Centerpod
14	3347780	353244		Hose, Pressure Switch