


Whirlpool WTW5310VQ0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool [Residential Whirlpool WTW5310VQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
3	3949550			Washer
4	3350389	285587		Washer
5	3347288			Agitator
6	8528150	W10445870		Ring-Tub
7	3976308			Gasket, Tub Ring
8	21366			Nut, Spanner
9	8526016	W10389328		Clothes Container, Assembly
10	387240			Ring, Balance
11	63849			Strain Relief, Power Cord
12	389140			Tub Block, Basket Drive
13	383727			Gasket, Centerpod
14	3347780	353244		Hose, Pressure Switch
15	2219077			Clip, Pressure Switch Hose
16	3354733	W10074580		Cap, Barrier

17	W10072840		Fabric Softener
18	3366877	80040	Dog-Agitator
19	3363661		Bearing, Driven Cam
20	3363663	285811	Cam-Agitator
21	3348752		Mover, Clothes
22	3348117	285565	Agitator

