


Whirlpool WTW5321SQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool WTW5321SQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	3400073			Screw, Ground
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	8579446			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577844	W10339251		Switch-WL

13	8544893		Bracket, Control
14	3956162	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	8541668		Clamp, Hose
18	8578341		Valve, Water Inlet W/Bi-Metal
19	303294	3367669	Protector, Edge
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	8539874		Shield, Suds
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8572717		Capacitor, Motor Start
29	8317975		Restraint, Harness
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
35	8578337		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	8541669		Bucket, Drain Hose
38	8541658		Bucket, Drain Hose
39	W10109060		Panel, Console
44	8566022		Knob, Timer
45	8566018		Dial,
46	8536939		Clip, Knob
47	8565944		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271359	279962	Endcap
52	8577378		U-Bend, Drain Hose
53	3347868	W10339879	Tie, Cable
54	3958079		Harness, Wiring

