


Whirlpool WTW5530SQ0 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool WTW5530SQ0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10044800			Installation Instructions
"	3955884			Use And Care Guide
"	3957874		Not Available	Feature Sheet
"	W10023610		Not Available	Energy Guide
"	8578911		Not Available	Wiring Diagram
"	4313896			Do-It-Yourself Repair Manuals
2	8543451	8543447		Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	8566266			Dispenser, Bleach
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
10	9724509			Bumper, Lid

11	8318084		Switch, Lid
12	3390631		Screw, 10-16 X 3/8
13	355274	W10119828	Screw, Lid Hinge Mounting
14	21097		Pad, Lid Hinge
15	8559336	W10225136	Hinge 7 Pad Assembly
16	91770		Hinge, Lid
17	8319539		Bearing, Lid Hinge
18	8580057	W10193861	Lid

