


Whirlpool WTW5550SQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool WTW5550SQ0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3400073			Screw, Ground
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	9740848			Screw, Mixing Valve Mounting
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	8577356			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577843	W10337781		Switch-WL

13	8544893		Bracket, Control
14	3956162	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
"	8271368	279965	Endcap
17	8572717		Capacitor, Motor Start
18	3979347	3979346	Valve, Water Inlet And Thermistor Assembly
19	8317975		Restraint, Harness
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8541668		Clamp, Hose
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
35	8578335		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3949187	W10168262	Switch, Rotary
39	8578789		Panel, Console
"	8578790		Panel, Console
41	8541669		Bucket, Drain Hose
42	8541658		Bucket, Drain Hose
44	8566022		Knob, Timer
"	8566025		Knob, Timer
45	8566018		Dial,
46	8536939		Clip, Knob
47	8565944		Knob, Control
"	8565947		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271359	279962	Endcap
"	8271362	279965	Endcap
52	8577378		U-Bend, Drain Hose
53	8539874		Shield, Suds
54	3347868	W10339879	Tie, Cable
55	W10044160		Wiring Harness