


# Whirlpool WTW5700AC0 02 - CONSOLE AND DISPENSER PARTS

## CONSOLE AND DISPENSER PARTS

For Model: WTW5700AC0  
(Chrome Shadow)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10504441

3

Whirlpool [Residential Whirlpool WTW5700AC0 Washer Parts](#) Parts Diagram 02 - CONSOLE AND DISPENSER PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10420428</a>			Console
2	<a href="#">W10251394</a>			Assembly, Knob White And Silver Models
3	<a href="#">W10269599</a>			User Interface
4	<a href="#">W10219342</a>			Screw, Baffle Mounting
5	<a href="#">8312709</a>			Clip-Console
6	W10445278	<a href="#">W10480126</a>		Control Unit Assembly, Machine And Motor
7	<a href="#">W10420984</a>			Panel, Console Rear Cover
8	3390647	<a href="#">488729</a>		Screw
9	1157158	<a href="#">489069</a>		Xxscrew, 10-12 X 1/2
10	<a href="#">W10280079</a>			Seal, Console
11	<a href="#">W10266797</a>			Cord, Power
12	<a href="#">3400076</a>			Screw, Bracket Mounting
13	<a href="#">W10432327</a>			Housing Assembly - Dispenser
14	<a href="#">W10240949</a>			Valve, Cold Water Inlet
15	<a href="#">W10240948</a>			Valve, Hot Water Inlet

16	W10343675	<a href="#">W10240967</a>	Harness, Valve
17	<a href="#">8281163</a>		Screw, Dispenser Housing Mounting
18	97787	<a href="#">W10109200</a>	Screw, Baffle Mounting
19	<a href="#">W10240946</a>		Bezel, Dispenser
20	W10420459	Not Available	DRAWER, DISPENSER ASSEMBLY
21	<a href="#">W10274524</a>		Tensioner, Facia
22	<a href="#">9740848</a>		Screw, Mixing Valve Mounting
23	<a href="#">W10325119</a>		Spacer, Knob
24	<a href="#">8536939</a>		Clip, Knob
25	<a href="#">W10285492</a>		Harness, User Interface
26	W10420457	Not Available	FACIA, DISPENSER

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>