


Whirlpool WTW5700XW1 02 - CONSOLE AND DISPENSER PARTS

CONSOLE AND DISPENSER PARTS

For Models: WTW5700XW1, WTW5700XL1
(White) (Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10411480

3

Whirlpool [Residential Whirlpool WTW5700XW1 Washer Parts](#) Parts Diagram 02 - CONSOLE AND DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10269606			Console
"	W10240515			Console
2	W10251392			Knob Assembly
3	W10269599			User Interface
4	W10219342			Screw, Baffle Mounting
5	8312709			Clip-Console
6	W10393444			Control Unit Assembly, Machine And Motor
7	W10269597			Panel, Console Rear Cover
8	3390647	488729		Screw
9	1157158	489069		Xxscrew, 10-12 X 1/2
10	W10280079			Seal, Console
11	W10266797			Cord, Power
12	3400076			Screw, Bracket Mounting
13	W10240963	W10432327		Housing Assembly - Dispenser
14	W10240949			Valve, Cold Water Inlet
15	W10240948			Valve, Hot Water Inlet

16	W10240967		Harness, Valve
17	8281163		Screw, Dispenser Housing Mounting
18	97787	W10109200	Screw, Baffle Mounting
19	W10240946		Bezel, Dispenser
20	W10240958		Drawer, Dispenser Assembly
21	W10274524		Tensioner, Facia
22	9740848		Screw, Mixing Valve Mounting
23	W10325119		Spacer, Knob
24	8536939		Clip, Knob

