


# Whirlpool WTW6200SW2 03 - MOTOR, BASKET AND TUB PARTS

## MOTOR, BASKET AND TUB PARTS

For Model: WTW6200SW2  
(White)



W10119752

5

Whirlpool [Residential Whirlpool WTW6200SW2 Washer Parts](#) Parts Diagram 03 - MOTOR, BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8566491</a>			Dispenser, Fabric Softener
2	<a href="#">W10076270</a>			Screw And Washer Assembly
3	<a href="#">W10076260</a>			Washer
4	W10108420	<a href="#">W10130806</a>		Tub Ring
5	8572540	<a href="#">353244</a>		Hose, Pressure Switch
6	<a href="#">W10076190</a>			Agitator
7	<a href="#">8533953</a>			Screw, 8-16 X 1.000
8	W10118114	<a href="#">280145</a>		Hub
9	8545953	<a href="#">280145</a>		Hub
10	W10118180	<a href="#">W10321522</a>		Basket
11	8572660	<a href="#">W10193886</a>		Tub-Outer
12	<a href="#">8577284</a>			Auger, Agitator
13	<a href="#">8542674</a>			Weight, Tub Counterbalance
14	<a href="#">W10004910</a>			Screw, 12-16 X 1-1/4
15	8557839	<a href="#">W10137698</a>		Shield, Drive Motor
16	8565172	<a href="#">280142</a>		Tube

17	8565170	<a href="#">W10419333</a>	Stator, Motor
18	<a href="#">8557836</a>		Plate, Stator
19	W10076010	<a href="#">8534042</a>	Screw, 1/4-20 X .968
20	8565188	<a href="#">W10183157</a>	Kit
21	8565177	<a href="#">280146</a>	Rotor
22	BLANK	Not Available	Bolt, Rotor Assembly Non-Serviceable (Supplied W/Rotor)
23	W10058730	<a href="#">W10183157</a>	Kit
24	8566197	<a href="#">W10222008</a>	Filter, Dual Pump Hood
25	<a href="#">8533928</a>		Screw, 8-18 X 3/4
26	<a href="#">8566279</a>		Spacer-Thrust
27	<a href="#">W10005430</a>		Clamp, Pressure Hose Retainer
28	<a href="#">8533957</a>		Screw, 10-16 X 1/2
29	<a href="#">W10076310</a>		Agitator, Assembly
30	<a href="#">W10074580</a>		Cap, Barrier
31	<a href="#">W10072840</a>		Fabric Softener
32	W10076210	<a href="#">280174</a>	Cam-Agitator
33	8558884	<a href="#">280160</a>	Roller
34	<a href="#">8578563</a>		Spacer, Thrust-Cam

