


# Whirlpool WTW6600SB3 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Models: WTW6600SW3, WTW6600SG3, WTW6600SB3  
(White) (Biscuit) (Black)

AUTOMATIC WASHER



1-08 Printed in U.S.A. (drd)

1

Part No. W10172465 Rev. B

[Whirlpool Residential Whirlpool WTW6600SB3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10113000		Not Available	Use & Care Guide
"	<a href="#">W10026571</a>			Tech Sheet
"	W10106480		Not Available	Quick Start Guide
"	8577781		Not Available	Wiring Diagram
"	W10165664		Not Available	Energy Guide
2	<a href="#">8565314</a>			Top
"	<a href="#">8565315</a>			Top
"	W10053420	<a href="#">W10211838</a>		Top
3	W10162416	<a href="#">W10180912</a>		Frame
4	<a href="#">8576784</a>			Sound Absorber, Cabinet
5	8566156	<a href="#">W10069980</a>		Cabinet
"	8566157	<a href="#">W10069990</a>		Cabinet
"	W10050330	<a href="#">W10070000</a>		Cabinet
6	<a href="#">8566090</a>			Panel, Rear
7	<a href="#">W10160572</a>			Retainer, Drain Hose Storage
8	<a href="#">3976348</a>			Absorber, Sound

9	W10111536	<a href="#">W10198919</a>	Kit
10	8566146	<a href="#">W10189077</a>	Suspension
11	1157158	<a href="#">489069</a>	Xxscrew, 10-12 X 1/2
12	<a href="#">W10042120</a>		Locator, Top
13	<a href="#">W10078270</a>		Screw, Lid Hinge Mounting
14	<a href="#">8563965</a>		Hinge Wire
"	<a href="#">8572974</a>		Hinge Wire
15	<a href="#">8563962</a>		Hinge, Spring Assembly
"	<a href="#">8563963</a>		Hinge, Spring Assembly
16	<a href="#">8563785</a>		Lock, Top- Front
17	<a href="#">W10052730</a>		Bearing, Lid Hinge
18	3390647	<a href="#">488729</a>	Screw
19	W10131139	<a href="#">W10183518</a>	Lid, Glass Assembly
"	W10131140	<a href="#">W10183519</a>	Lid
"	W10131141	<a href="#">W10183520</a>	Lid, Glass Assembly
20	8578826	<a href="#">W10397767</a>	Foot Assembly, Leveling
21	W10059150	<a href="#">W10172146</a>	Dispenser, Fabric Softener
22	<a href="#">8566210</a>		Bezel, Fabric Softener Dispenser
"	<a href="#">8580016</a>		Bezel, Fabric Softener Dispenser
"	<a href="#">8580017</a>		Bezel, Fabric Softener Dispenser
23	<a href="#">W10161865</a>		Dispenser, Stain Remover
24	<a href="#">8566211</a>		Bezel, Stain Remover Dispenser
"	<a href="#">8580018</a>		Bezel, Stain Remover Dispenser
"	<a href="#">8580019</a>		Bezel, Stain Remover Dispenser
25	<a href="#">8564976</a>		Dispenser, Detergent
"	<a href="#">W10059170</a>		Dispenser, Detergent
"	W10059180	<a href="#">W10131104</a>	Dispenser
26	<a href="#">8564979</a>		Bezel, Detergent Dispenser
"	<a href="#">W10045190</a>		Bezel, Detergent Dispenser
"	<a href="#">W10045210</a>		Bezel, Detergent
27	<a href="#">W10106990</a>		Nozzle Assembly, Fresh Water
28	371503	<a href="#">596669</a>	Clamp, Manifold
29	<a href="#">W10059230</a>		Lock Assembly, Lid
30	<a href="#">8572019</a>		Bezel, Lid Lock
"	<a href="#">8563939</a>		Bezel, Lid Lock
"	<a href="#">W10052520</a>		Bezel, Lid Lock
31	<a href="#">8564458</a>		Absorber, Impact
32	<a href="#">8564456</a>		Hinge, Top
33	<a href="#">18849</a>		Pad, Top Hinge
34	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
35	<a href="#">8563941</a>		Cover, Harness
36	<a href="#">693995</a>		Screw, Hex Head
37	<a href="#">8543784</a>		Bracket, Drain Hose
38	<a href="#">8578386</a>		Shield, Wire Harness
39	<a href="#">8281136</a>		Screw, 10-16 X 3/4
40	<a href="#">8576476</a>		Spacer, Rear
41	370451	<a href="#">596669</a>	Clamp, Manifold
42	371503	<a href="#">596669</a>	Clamp, Manifold

43	<a href="#">3400061</a>		Screw, Dispenser Housing Mounting
44	<a href="#">90016</a>		Clip, Pressure Switch Hose
45	8281736	<a href="#">3184020</a>	Wire
46	<a href="#">3400076</a>		Screw, Bracket Mounting
47	<a href="#">8577896</a>		Washer, Suspension Umbrella
48	<a href="#">8564017</a>		Cup, Suspension
49	W10167599	<a href="#">W10198919</a>	Kit

