


Whirlpool WTW6600SG0 01 - TOP AND CABINET PARTS



5-06 Printed In U.S.A. (drd)

1

Part No. 8181164

Whirlpool Residential Whirlpool WTW6600SG0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8566931			Use And Care Guide
"	8567470		Not Available	Installation Instructions (DVD)
"	8567037		Not Available	Tech Sheet
"	8566929		Not Available	Quick Start Guide
"	8577781		Not Available	Wiring Diagram
"	8567168		Not Available	Energy Guide
2	8565311	8565314		Top
"	8565312	8565315		Top
"	W10053420	W10211838		Top
3	8576639	W10180912		Frame
4	8576784			Sound Absorber, Cabinet
5	8566156	W10069980		Cabinet
"	8566157	W10069990		Cabinet
"	W10050330	W10070000		Cabinet
6	8566090			Panel, Rear
7	8543781	W10160572		Retainer, Drain Hose Storage

8	8578225		Absorber - Sound, Cabinet Front
9	8576475	W10198919	Kit
10	8564009	W10189077	Suspension
11	1157158	489069	Xxscrew, 10-12 X 1/2
12	8563602	W10042120	Locator, Top
13	W10078270		Screw, Lid Hinge Mounting
14	8563965		Hinge Wire
"	8572974		Hinge Wire
15	8563962		Hinge, Spring Assembly
"	8563963		Hinge, Spring Assembly
16	8563785		Lock, Top- Front
17	W10052730		Bearing, Lid Hinge
19	8565267	W10183518	Lid, Glass Assembly
"	8576485	W10183519	Lid
"	W10071520	W10183520	Lid, Glass Assembly
20	8578826	W10397767	Foot Assembly, Leveling
21	W10059150	W10172146	Dispenser, Fabric Softener
"	W10052670		Dispenser, Fabric Softener
"	W10052680		Dispenser, Fabric Softener
22	8566210		Bezel, Fabric Softener Dispenser
"	8580016		Bezel, Fabric Softener Dispenser
"	8580017		Bezel, Fabric Softener Dispenser
23	W10059160		Dispenser, Bleach
"	W10052690		Dispenser, Bleach
"	W10052700		Dispenser, Bleach
24	8566211		Bezel, Stain Remover Dispenser
"	8580018		Bezel, Stain Remover Dispenser
"	8580019		Bezel, Stain Remover Dispenser
25	8564976		Dispenser, Detergent
"	W10059170		Dispenser, Detergent
"	W10059180	W10131104	Dispenser
26	8564979		Bezel, Detergent Dispenser
"	W10045190		Bezel, Detergent Dispenser
"	W10045210		Bezel, Detergent
27	8543779	W10106990	Nozzle Assembly, Fresh Water
28	371503	596669	Clamp, Manifold
29	W10059230		Lock Assembly, Lid
30	8572019		Bezel, Lid Lock
"	8563939		Bezel, Lid Lock
"	W10052520		Bezel, Lid Lock
31	8564458		Absorber, Impact
32	8564456		Hinge, Top
33	18849		Pad, Top Hinge
34	343641	681414	Screw, 10AB X 1/2
35	8563941		Cover, Harness
36	693995		Screw, Hex Head
37	8543784		Bracket, Drain Hose
39	8281136		Screw, 10-16 X 3/4

40	8576476		Spacer, Rear
41	370451	596669	Clamp, Manifold
42	371503	596669	Clamp, Manifold
43	3400061		Screw, Dispenser Housing Mounting
44	90016		Clip, Pressure Switch Hose
45	8281736	3184020	Wire
46	3400076		Screw, Bracket Mounting
47	3390647	488729	Screw
48	8577896		Washer, Suspension Umbrella

