


Whirlpool WTW6600SG1 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: WTW6600SW1, WTW6600SG1, WTW6600SB1
(White) (Biscuit) (Black)

AUTOMATIC WASHER



2-07 Printed in U.S.A. (drd)

1

Part No. W10114870 Rev. A

Whirlpool Residential Whirlpool WTW6600SG1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10106470		Not Available	Use & Care Guide
"	W10026571			Tech Sheet
"	W10106480		Not Available	Quick Start Guide
"	8577781		Not Available	Wiring Diagram
"	W10107030		Not Available	Energy Guide
2	8565311	8565314		Top
"	8565312	8565315		Top
"	W10053420	W10211838		Top
3	W10114656	W10180912		Frame
4	8576784			Sound Absorber, Cabinet
5	8566156	W10069980		Cabinet
"	8566157	W10069990		Cabinet
"	W10050330	W10070000		Cabinet
6	8566090			Panel, Rear
7	8543781	W10160572		Retainer, Drain Hose Storage
8	8578225			Absorber - Sound, Cabinet Front

9	W10111536	W10198919	Kit
10	8564009	W10189077	Suspension
11	1157158	489069	Xxscrew, 10-12 X 1/2
12	W10042120		Locator, Top
13	W10078270		Screw, Lid Hinge Mounting
14	8563965		Hinge Wire
"	8572974		Hinge Wire
15	8563962		Hinge, Spring Assembly
"	8563963		Hinge, Spring Assembly
16	8563785		Lock, Top- Front
17	W10052730		Bearing, Lid Hinge
18	489290	488488	Screw
19	8565267	W10183518	Lid, Glass Assembly
"	8576485	W10183519	Lid
"	W10071520	W10183520	Lid, Glass Assembly
20	8578826	W10397767	Foot Assembly, Leveling
21	W10059150	W10172146	Dispenser, Fabric Softener
"	W10052670		Dispenser, Fabric Softener
"	W10052680		Dispenser, Fabric Softener
22	8566210		Bezel, Fabric Softener Dispenser
"	8580016		Bezel, Fabric Softener Dispenser
"	8580017		Bezel, Fabric Softener Dispenser
23	W10059160		Dispenser, Bleach
"	W10052690		Dispenser, Bleach
"	W10052700		Dispenser, Bleach
24	8566211		Bezel, Stain Remover Dispenser
"	8580018		Bezel, Stain Remover Dispenser
"	8580019		Bezel, Stain Remover Dispenser
25	8564976		Dispenser, Detergent
"	W10059170		Dispenser, Detergent
"	W10059180	W10131104	Dispenser
26	8564979		Bezel, Detergent Dispenser
"	W10045190		Bezel, Detergent Dispenser
"	W10045210		Bezel, Detergent
27	W10106990		Nozzle Assembly, Fresh Water
28	371503	596669	Clamp, Manifold
29	W10059230		Lock Assembly, Lid
30	8572019		Bezel, Lid Lock
"	8563939		Bezel, Lid Lock
"	W10052520		Bezel, Lid Lock
31	8564458		Absorber, Impact
32	8564456		Hinge, Top
33	18849		Pad, Top Hinge
34	343641	681414	Screw, 10AB X 1/2
35	8563941		Cover, Harness
36	693995		Screw, Hex Head
37	8543784		Bracket, Drain Hose
38	8578386		Shield, Wire Harness

39	8281136		Screw, 10-16 X 3/4
40	8576476		Spacer, Rear
41	370451	596669	Clamp, Manifold
42	371503	596669	Clamp, Manifold
43	3400061		Screw, Dispenser Housing Mounting
44	90016		Clip, Pressure Switch Hose
45	8281736	3184020	Wire
46	3400076		Screw, Bracket Mounting
47	3390647	488729	Screw
48	8577896		Washer, Suspension Umbrella
49	8564017		Cup, Suspension

the laundry company[®]

the laundry company[®]

the laundry company[®]